


HOUSING-DRIVE SIDE




ref #	item #	description
1	90-0258-0000	csk screw m4x10
2	90-0001-0000	crph screw m3x6
7	90-0143-0000	csk screw m6x14
9	90-0293-0000	allen screw m6x10
10	90-0144-0000	allen screw m6x16
11	90-0005-0000	allen screw m6x20
13	90-0007-0000	washer 4.2x12x1.6
19	CAS88	bearing 6003 2rs
20	90-0121-0000	bearing 608 2z
24	90-0011-0000	belt 500 5 m
25	90-0012-0000	belt 425 5 m
28	90-0152-0000	washer
32	90-0154-0000	bumper front
34	90-0156-0000	bumper
42	90-0024-0000	brush slider
43	90-0025-0000	slider housing
46	90-0027-0000	seal
49	90-0029-0000	pinion
53	90-0031-0000	drum sprocket
59	90-0035-0000	pin
62	90-0176-0000	o-ring
63	90-0040-0000	shield
73	90-0183-0000	self tapping screw

ref #	item #	description
77	90-0020-0000	cap
80	90-0285-0000	gear housing
83	CAS117	housing sprocket
84	90-0264-0000	seal
87	90-0286-0000	gear - lh
88	90-0287-0000	gear - rh
92	90-0267-0000	shield
93	90-0294-0000	roller
105	90-0390-0000	bumper sleeve
111	CAS93	brush sprocket
114	90-0063-0000	gear sprocket
115	90-0065-0000	idler assembly
115a	90-0169-0000	sprocket
115b	90-0161-0000	hub
116	90-0197-0000	idler assembly
116a	90-0166-0000	sleeve
212	90-0392-0000	stub axle
V8	552580180	cover

\*call for pricing and availability of all referenced parts

## HOUSING-IDLE SIDE




ref #	item #	description
1	90-0258-0000	csk screw m4x10
2	90-0001-0000	crph screw m3x6
6	90-0261-0000	csk screw m5x25
9	90-0293-0000	allen screw m6x10
10	90-0144-0000	allen screw m6x16
13	90-0007-0000	washer 4.2x12x1.6
15	90-0147-0000	washer 6.4x12x1.6
16	90-0395-0000	washer 9x17x1.6
17	90-0298-0000	spring washer m6
18	90-0148-0000	toothed washer m6
19	CAS88	bearing 6003 2rs
21	90-0149-0000	wire tie
32	90-0154-0000	bumper
33	90-0155-0000	bush
34	90-0156-0000	bumper
39	90-0123-0000	stub axle
43	90-0025-0000	slider housing
46	90-0027-0000	seal
58	90-0033-0000	slider transport
59	90-0035-0000	pin
62	90-0176-0000	o' ring
63	90-0040-0000	shield
68	90-0179-0000	fan cover
72	90-0045-0000	grommet
73	90-0183-0000	self tapping screw
75	90-0048-0000	cap
77	90-0020-0000	cap
79	90-0188-0000	stopper
81	90-0259-0000	pedal


ref #	item #	description
86	90-0297-0000	nut
89	90-0269-0000	connector
92	90-0267-0000	shield
93	90-0294-0000	roller
94	90-0290-0000	socket assembly
94a	90-0291-0000	socket
94b	90-0292-0000	terminal
95	90-0278-0000	cable
96	90-0279-0000	cable
97	90-0280-0000	cable
98	90-0281-0000	cable
100	90-0260-0000	spring-pedal
105	90-0390-0000	bumper sleeve
106	90-0396-0000	csk screw m4x8
129	90-0265-0000	lever switch act
131	90-0262-0000	insulation top
132	90-0263-0000	insulation bottom
133	90-0295-0000	nut
188	90-0397-0000	sleeve tie rod
212	90-0392-0000	stub axle
242	33864	clamp wire
248	33865	cable assembly
252	33866	switch 21a
313	552580189	electrical assembly - 34t-110v
V3	90-0056-0000	circuit breaker (10a)
V5	552580172	idle housing-blue
V8	552580180	cover-blue
V11	552580174	housing assembly complete
V	552580182	cover assembly complete

\*call for pricing and availability of all referenced parts

PUMP HOUSING



LEVER AND GUIDE LINK MECHANISM




ref #	item #	description
13	90-0007-0000	washer
40	90-0101-0000	gasket
72	90-0045-0000	grommet
102	90-0113-0000	filter
103	90-0192-0000	body-valve-34t
107	90-0224-0000	seal-w34t
121	90-0007-0000	dirty water tank
122b	90-0055-0000	lid pad
123	90-0075-0000	lid assembly-dirty water
123	90-0184-0000	lid-dirty water
154	90-0104-0000	hose-275
165	90-0141-0000	hex nut m4
168	90-0349-0000	strip lid
170	90-0403-0000	hose-165
173	90-0404-0000	hose connector
174	90-0405-0000	boot-lid
249	33879	capacitor-63.5mfd
270	33874	washer m4x12x0.5
271	33875	crph screw m4x16
277	818106	crph screw m4x16
278	90-0074-00	lid tank
279	552530028	cap valve-34t-110v
280	90-0409-000	tank assembly w/label

ref #	item #	description
4	90-0046-0000	crph screw m4x12
26	90-0151-0000	clevis pin
29	90-0153-0000	clevis pin
41	90-0159-0000	link
45	90-0286-0000	shield
47	90-0163-0000	lever
64	90-0177-0000	lever button
76	90-0051-0000	circlip
78	90-0186-0000	link guide
82	90-0284-0000	spring
91	90-0257-0000	bush
113	90-0196-0000	wheel
118	90-0068-0000	lever assembly
118a	90-0173-0000	lever
119	90-0069-0000	lever assembly
119a	90-0174-0000	lever
120	90-0070-0000	lever assembly
120a	90-0175-0000	lever
128	90-0266-0000	lever switch

\*call for pricing and availability of all referenced parts


## MOTOR, DRUM AND BRIDGE ASSEMBLY



ref #	item #	description
5	90-0142-0000	hex nut m6
7	90-0143-0000	csk screw m6x14
8	90-0004-0000	allen screw m4x10
14	90-0146-0000	washer 5.2x10x1.6
15	90-0147-0000	washer 6.4x12x1.6
22	90-0150-0000	grub screw m5x12
27	90-0015-0000	bush
28	90-0152-0000	washer
31	90-0017-0000	washer
37	90-0157-0000	spring
38	90-0158-0000	spring
50	90-0167-0000	hex shaft
51	90-0030-0000	washer

ref #	item #	description
54	90-0170-0000	tie rod
55	90-0171-0000	shaft
56	90-0172-0000	roller
67	90-0178-0000	bush
69	90-0180-0000	bush
70	90-0181-0000	bush
112	90-0062-0000	brush shaft
134	90-0306-0000	drum assembly
134b	90-0304-0000	drum sleeve
V1	90-0193-0000	motor (110v//60hz)
V6	552580186	bridge assembly-blue

\*call for pricing and availability of all referenced parts



ref #	item #	description
3	90-0002-0000	crph screw
4	90-0046-0000	crph screw
11	90-0005-0000	allen screw
12	90-0006-0000	washer
23	90-0010-0000	cable retainer
35	90-0018-0000	clamp
44	90-0026-0000	pull handle
48	90-0165-0000	cap
52	90-0168-0000	base-cable holder
57	90-0032-0000	clamp
60	90-0038-0000	nut
65	90-0041-0000	spring
66	90-0042-0000	washer
71	90-0044-0000	plug
73	90-0183-0000	self tapping screw
117	90-0067-0000	top handle
126	90-0296-0000	knob
135	90-0235-0000	bottom handle
152	90-0101-0000	gasket
153	90-0103-0000	tank-4l

ref #	item #	description
160	90-0110-0000	base valve
160a	90-0202-0000	base
160b	90-0206-0000	seal
160c	90-0210-0000	cap-valve
161	90-0111-0000	valve
161a	90-0203-0000	body-valve
161b	90-0341-0000	seal
161c	90-0229-0000	spring
161d	90-0204-0000	cap-spring
179	90-0092-0000	nut
189	33881	sleeve
224	90-0402-0000	knob-cable holder-ii
225	90-0429-0000	knob-cable holder-i
226	90-0443-0000	knob-tank holder-lh
227	90-0444-0000	knob-tank holder-rh
228	90-0445-0000	base-cable and tank holder
229	33882	guide-110v
230	90-0451-0000	pipe-lh
231	90-0452-0000	pipe-rh
281	552580183	pull cable assembly
v4	33883	power cord-yellow

\*call for pricing and availability of all referenced parts